

How to configure dynamic IP on a Huawei optical switch



AI Overview

To configure a dynamic IP on a Huawei optical switch, enable the DHCP client on the target interface or VLAN, allowing the switch to automatically obtain an IP address from a DHCP server.

Steps to Configure Dynamic IP

1. Access the Switch CLI Connect to the switch via console, SSH, or Telnet. Enter system view mode to start configuration:
`CodeCopy system-view`
2. Select the Interface or VLAN Choose the interface or VLAN interface (VLANIF) that will obtain a dynamic IP. For example, to configure VLAN 10:
`CodeCopy interface Vlanif 10`
3. Enable DHCP Client Activate the DHCP client on the interface so it can request an IP address from a DHCP server:
`CodeCopy dhcp select client` This command enables the interface to automatically obtain an IP address, subnet mask, default gateway, and DNS settings from the DHCP server.
4. Configure Optional DHCP Parameters You can configure lease times or static bindings if needed, but for dynamic IP, the default DHCP allocation is sufficient. For example, to set a lease time:
`CodeCopy dhcp server lease day 1` This is optional and mainly used when the switch also acts as a DHCP server.
5. Verify the Configuration Exit configuration mode and check the assigned IP address:
`CodeCopy display ip interface brief` This command lists all interfaces and their current IP addresses, confirming that the interface has obtained a dynamic IP.
6. Save the Configuration To ensure the settings persist after a reboot:
`CodeCopy save`

Additional Considerations

- VLAN Configuration:** Ensure the interface is added to the correct VLAN if using VLANIF interfaces. For example:
`CodeCopy interface GigabitEthernet 0/0/1 port link-type access port default vlan 10`
- DHCP Relay:** If the DHCP server is on a different subnet, enable DHCP relay on the switch to forward requests:
`CodeCopy dhcp relay server-ip`
- Multiple Interfaces:** Each interface requiring...

Article Content

FAQ How to configure dynamic vlan assignment via radius

This case will reveal how to configure dynamic vlan assignment via radius. In some situation you would like to bind a mac-address to a specific VLAN and allow a host to get access the

Die Historischen Analogkameras

60 jahre geballtes Fachwissen zu historischen Kameras. Jeden Monat neu.

Huawei Switch Setup | VLAN Creation and IP Assignment Explained

Learn how to configure VLAN and assign IP addresses on a Huawei Switch step by step. In this tutorial, we cover VLAN creation, interface configuration, and IP assignment for proper network ...

Enterprise High-Availability: VRRP, MLAG & ECMP

How it works: Imagine a floor of 100 office computers needing a "Default Gateway" IP address. With VRRP, you deploy two Layer 3 switches

zxcvbn-rs/src/frequency_lists.rs at master

Port of Dropbox's zxcvbn password strength library for Rust - shssoichiro/zxcvbn-rs

Static Routes and Dynamic Routes

This document describes IP Unicast Routing configurations supported by the switch, including the principle and configuration procedures of IP Routing Overview, Static Route, RIP, RIPng, OSPF,

Management Interfaces and Management IP Addresses of S Series Switches ...

Overview To manage a switch, you need to use its management interface and management IP address. This document describes the management interfaces supported by switches and how to configure

Management Interfaces and Management IP Addresses of S Series

This document describes the management interfaces supported by switches and how to configure management IP addresses for switches.

Huawei Network Switch Configuration guide | Step-by-Step CLI

📖 Learn how to fully configure a Huawei S5700 Series switch step-by-step using real CLI commands!

Example for Configuring Dynamic NAT

The configuration roadmap is as follows: Configure IP addresses for ports, default route, and outbound NAT on the WAN interface to allow internal hosts to access external networks.

Network Admin's Must-Know: How to Change IP Address on Huawei

Whether you're troubleshooting connectivity issues or segmenting networks for enhanced security, mastering how to change IP address on Huawei switch proves critical.

HUAWEI S6700 SERIES CONFIGURATION MANUAL Pdf Download

On an IPv4 network, configuring BFD for IPv4 static routes on the public network can speed up route convergence and improve network reliability. 1.6 Configuration Examples This section provides

How to Assign an IP Address in a Huawei Switch? Why Proper ...

Mastering IP address assignment on a Huawei switch isn't about memorizing commands—it's about understanding how this single task weaves into your network's DNA.

Connecting to a WAN Using a Dynamic IP Address

Configuration Notes If you configure WAN access using a dynamic IP address through the web, the router's interface connecting to internal users must be VLANIF 1.

Huawei CloudEngine S5755-S Series Twins Switches Datasheet

Introduction Huawei CloudEngine S5755-S-HT series twins switches are next-generation, high-reliability switching platforms. The series delivers system-level reliability through an innovative architecture

01-03 DHCP CONFIGURATION

For each client using BOOTP, a network administrator must configure a BOOTP parameter file that requires manual intervention to modify. DHCP improves on BOOTP by dynamically allocating IP

S600-E V200R022C00 Configuration Guide

Configure the switch as a DHCP server to dynamically allocate IP addresses on the two network segments and the DNS server IP address to enterprise terminals. Allocate IP addresses on

gpt4_vocab_list/o200k_base_vocab_list.txt at main

Vocabulary list of GPT-4o (o200k_base) and GPT-4/GPT-3.5 (cl100k_base) tokenizers. Special tokens are excluded. - kaisugi/gpt4_vocab_list

Achieving Line-Rate Forwarding: Buffer Allocation and QoS

Core Architecture & Switching Logic: The Hardware Foundation for Line-Rate Forwarding The Huawei AR series is engineered to achieve high-throughput and low-latency performance through a purpose

(PDF) Analysis of Dynamic Host Control Protocol

Abstract Dynamic Host Control Protocol (DHCP) is a protocol which provides IP addresses and network configuration parameters to the hosts

01-03 DHCP CONFIGURATION

DHCP improves on BOOTP by: Dynamically allocating IP addresses and configuration parameters to hosts. Enabling a host to dynamically obtain an IP address without specifying an IP address for each

Configuring Attributes for an Optical Interface

After configuring interface split or merge on an interface, you need to save the configuration and restart the switch to make the configuration take effect. The original configuration

Huawei Switch Configuration Guide | PDF | Internet Protocols

The document provides configuration instructions and commands for basic switch configuration using Huawei switches. It covers topics such as changing the hostname, configuring user accounts and

Example for Configuring IPSG Based on the DHCP Snooping Dynamic

Configure DHCP snooping on Switch_1. Hosts can then obtain IP addresses from the valid DHCP server, and the DHCP server can generate DHCP snooping dynamic binding entries. These entries

Rick Astley

The official video for “Never Gonna Give You Up” by Rick Astley. Never: The Autobiography  OUT NOW! Follow this link to get your copy and listen to Rick's ...

HUAWEI S9300 CONFIGURATION MANUAL Pdf Download

View and Download Huawei S9300 configuration manual online. Terabit Routing Switch. S9300 switch pdf manual download. Also for: S9300e.

Contact Us

For more information, pricing, or custom solutions, please contact us:

Website: <https://www.mr-security.co.za>

Email: info@mr-security.co.za

Phone: +33 1 45 23 67 81

Address: 10 Rue de la Paix, 75002 Paris, France

This document is for informational purposes only. Specifications subject to change without notice.

